

You will find the connections for the Target "Scheibe" and the External button "Drücker at the control unit. You will also find the programs you can select. For power supply, the device must be connected to a standard powerbank, a mobile phone or a PC via the USB cable.

You can operate the device either by pressing the Start button on the device or by using the External button.

Scheibe 1. SFP 8 Sekunden 2. SFP 6 Sekunden 3. SFP 4 Sekunden 4. Sportpistole Duell 5. Haltetraining 6. Standardpistole 20 S 7. Standardpistole 10 S. Drücker

kurzes Drücken Start des Programmes langes Drücken Wechsel zum Nächsten

Pressing the button for a long time changes the program, short press starts the selected program. As soon as you change the program, you will be shown by the colour of the lights in which program you are currently in.

The programs sport pistol rapid fire "Sportpistole Duell" and holding exercises "Haltetraining" run as a continuous loop and can be stopped by pressing the Start button again. In "Haltetraining" the green light turns on for 60 seconds, then the red for 15 seconds.

All other programs run as usual with 7 seconds of lead time and are shown only once.

If you want to finish your dry firing simply disconnect the device from power.